



No matter how well you maintain your inflatable, there is always a possibility that it has to be cleaned. For this purpose we have HG mould spray and mildew cleaner available. It immediately and effortlessly eliminates all moulds, making filthy black stains disappear. Spray HG mould spray on the surface from a distance of 3 to 5 cm. For heavily soiled surfaces, we recommend repeating this treatment after 10 minutes. Allow the product to work for 30 minutes and clean with water and a sponge. Your object will look like new again!



Inflated product

Amount of packages

Specifications packaged product

1x

General

SKU 77.100.002.220